

# 工业缝切机数控交流伺服系统简易操作说明

## 1. 安全事项

- 为了安全、正确地使用工业缝切机伺服系统及其附属设备，使用前请务必认真阅读【安全事项】。在熟知设备知识、安全信息及注意事项后进行使用。
- 阅读后，请务必牢记以便遵守。

以下列出在使用操作工业缝切机伺服系统过程中需要注意以及禁止的各方面内容。另外，可能还会发生书中所载内容的以外的严重后果，敬请严格遵守。

- 在使用前请务必仔细阅读以下安全事项，避免一切在以下内容中所提及的注意事项以及严禁事项！

### 1.1 关于工作环境

- 电源电压请遵照产品铭牌所示的电压范围接入。
- 请远离电磁波干扰源，以免产生的电磁波干扰影响本系统而发生错误动作。
- 请勿将本设备置于温度低于5℃或高于45℃的环境下使用。
- 请勿将本设备置于湿度低于30%或高于80%的环境下使用。
- 请尽量避免对环境进行除尘处理。
- 保持设备周围环境温度，勿将设备置于发热体周围运行。

### 1.2 关于设备安装

- 请严格按照说明书所示对本设备的各个部件进行安装。
- 当需要更换针线、翻线机头、插接连接插头时，必须断开电源。
- 电源线的接地线必须以适当大小的导线和接头连接到生产工厂的系统接地线，此链接必须永久固定。

### 1.3 关于运行

- 首次开机通电时，请以低速运行方式检查转动方向是否正确。
- 接通电源开关时请勿进行任何脚踏操作。
- 在正式运行工作之前，请务必确认所有的设定参数、开关是否正常运作。
- 当缝纫机在运行过程中出现断线、断针等运动部件。
- 当发生报警时，应排除原因，并确保安全后，再重新进行报警设定，重新进行运行。
- 不可频繁打开或关闭本设备电源。

### 1.4 关于保养

- 控制箱内有高压电，开启电控箱盖必须断电5分钟以上。
- 保养及维修时，必须由经过专业培训的人员进行操作。
- 维修所需的所有零部件，必须由本公司提供或认可，方可使用。

### 1.5 技术规格

额定输入电压	220V±10%
额定输入频率	50/60HZ
额定输出功率	550W/750W
电机最大转速	5000rpm/3500rpm

第1页

## 2. 上针位设置与调整

### 重要

在系统安装好后首次上电运行前，必须确保将上针位设置到合理区域，忽略或者错误设置此步骤，将会导致缝切机无法正常运行，出现断针、剪不断线、机械卡死等现象。

1. 在关机状态，按S键，同时开启电源为系统上电，系统启动后即进入特殊功能设置模式。

2. 进入特殊功能设置模式后，显示屏将自动弹出特殊功能设置模式，同时可以通过一下键来选择代码号。

3. 将功能代码设置为：8080 即为执行自动上针位设置的代码。

4. 手动转动手轮，调整到所需的上针位(即绣线针最高位置)或者直接将手轮上的上针位标志①与磁钢机头的标志②对准。此时缝切机针的位置出厂时的标志上针位。

5. 调整好所需上针位后，按S键即可执行该功能(此时显示屏闪烁，电机停在所述上针位上，表示完成上针位的设置)步骤(3)所示的针位将被设置为上针位，上针位的设置过程完成。

(备注：以下有部分机型适用，具体机型请咨询客服) 设置完成后的位置与步骤(3)调整的位置有差异，可以进行步骤(5)进行手动微调。

(备注：以下有部分机型适用，具体机型请咨询客服) 通过上下加减键对上针位的微调，按下按键的同时，电机实时微动，直观的进行显示是否调整到位。

当微调到理想位置时，按下脚踏检测针位是否仍为设置位置，可重复微调，直至达到理想位置为止。至此即完成上针位设置。

第2页

## 3. 操作说明

### 3.1 按键显示功能对照表:

功能	按键	说明	显示图标
功能参数编辑键	P	进入或退出功能参数的编辑;在缝切机状态下按键2~3秒进入参数编辑状态,在参数编辑状态下按键2~3秒退出参数编辑状态返回缝切机状态	—
参数查看保存键	S	对所选参数号内容进行查看和保存,选择好参数号后按此键可以进行查看和修改操作,修改参数值后按此键退出并保存参数	—
速度增减键	▲ / ▼	加速键:提高运行速度 减速键:降低运行速度	—
参数增减键	➕ / ➖	增大参数键 减小参数键	—
切换键	↻	针数、参数设置切换键	—
自动缝切功能键	⊙	(只在定长缝中有效)当触发功能键激活时,显示屏显示图标,触发脚踏,自动走设定定的缝切过程	⊙
停针位置选择键	⏸	选择停车时的上下停针位,默认状态为上停针位,当显示屏显示图标时表示选择上下停针位	⏸
慢速启动设定键	⏪	慢速启动设定,当显示屏显示图标时,启动慢速启动功能。	⏪
中途停车自动抬压脚踏设定键	⏹	设置中途停车时是否自动抬压脚踏,当显示屏显示图标时,激活中途停车自动抬压脚踏功能	⏹
剪线自动抬压脚踏设定键	✂	剪线后自动抬压脚踏,当显示屏显示图标时,激活剪线后自动抬压脚踏功能	✂
连续回缝设定键	↺	连续回缝功能设定,当显示屏显示图标时,激活连续回缝(键)功能	↺
自由键设定键	⏩	自由功能设定,当显示屏显示图标时,激活自由功能	⏩
起始回缝设定键	↻	起始回缝功能设定,按一次激活起始回缝,按两次激活起始回缝,连续按,将在起始回缝和起始回缝来回切换	↻
终止回缝设定键	↻	终止回缝功能设定,按一次激活终止回缝,按两次激活终止回缝,连续按,将在终止回缝和终止回缝来回切换	↻
定长缝设定键	⏸	执行段长设定,当显示屏显示图标时,激活段长缝功能,连续按,将循环切换四段,自定义多段缝模式,显示屏显示相应图标	⏸
剪线开关	✂	设置是否剪线功能,当显示屏显示图标时,激活剪线功能	✂
提针与补针	⏪	执行补针,提针功能,详见功能说明	—
夹线器开关	⏸	设置是否开启夹线器功能,当显示屏显示图标时,激活该功能	⏸

第3页

## 4. 系统接线说明

脚踏脚

脚踏脚	1	+5V
	2	数字地
	3	-
	4	启动信号
	5	剪刀信号
	6	加速信号

电磁铁

电磁铁	1	AC220
	2	AC220
	3	接地

脚踏板

脚踏板	1	+32V
	2	+32V
	3	32V数字地
	4	补针开关
	5	32V数字地
	6	32V数字地
	7	32V数字地
	8	32V数字地
	9	32V数字地
	10	32V数字地
	11	32V数字地
	12	32V数字地
	13	32V数字地
	14	32V数字地

电源输入

电源输入	1	AC220
	2	AC220
	3	接地

一体机电控-电磁铁接线

电磁铁	1	+32V
	2	32V数字地
	3	32V数字地
	4	补针开关
	5	32V数字地
	6	32V数字地
	7	32V数字地
	8	32V数字地
	9	32V数字地
	10	32V数字地
	11	32V数字地
	12	32V数字地
	13	32V数字地
	14	32V数字地

分体机电控-电磁铁接线

电磁铁	1	+32V
	2	+32V
	3	32V数字地
	4	补针开关
	5	32V数字地
	6	32V数字地
	7	32V数字地
	8	32V数字地
	9	32V数字地
	10	32V数字地
	11	32V数字地
	12	32V数字地
	13	32V数字地
	14	32V数字地

### 5. 操作模式选择

#### 5.1 一般缝切模式

正常对系统上电后，默认进入一般缝切模式。在此模式下，用户可在已设定好技术参数的前提下选择使用各种缝切功能。在此模式下，用户可依据需要切换各种缝切功能进行缝切工作，但无法对系统各类技术参数进行修改和设置。

#### 5.2 用户参数设置模式

- 在用户参数设置模式下，可以根据缝制需要调整各类缝切功能的技术参数，参数设定步骤如下：
- 在一般缝切模式下按P键2~3秒进入用户参数设置模式。
  - 进入用户参数设置模式后默认参数选择界面，同时可以通过“←”键来选择参数号。
  - 选择好参数号后按S键进入参数修改界面进行参数查看，可以通过“←”键来设置参数值。
  - 设置参数值后按S键保存参数值并退出参数修改界面。
  - 按P键2秒退出系统参数设置模式，返回一般缝切模式。

#### 5.3 系统参数设置模式

- 在系统参数设置模式下，可以根据缝制需要调整各类电磁铁参数以及系统设置，参数设定步骤如下：
- 在关机状态，按S键，同时开启电源为系统上电，系统启动后即进入系统参数设置模式。在此模式下，可以对系统参数进行修改，同时也可以对用户参数进行修改。
  - 通过“←”键来选择参数号，按下S键进入参数修改界面进行参数查看和修改。
  - 设置参数值后按S键保存参数值并退出参数修改界面。
  - 按P键2秒退出系统参数设置模式，返回一般缝切模式。

第4页

## 用户参数表 V1.4

参数号	名称	出厂值	范围	说明
Fn-01	最高转速(r/min)	3600	100~5000	最高转速
Fn-02	加速曲线调整(%)	80	10~150	控制脚踏加速曲线斜率设定
Fn-03	起始回缝速度(r/min)	1800	150~2800	起始回缝速度
Fn-04	终止回缝速度(r/min)	1800	150~2800	终止回缝的速度设定
Fn-05	连续回缝速度(r/min)	1800	150~2800	连续回缝速度设定
Fn-06	慢速启动速度(r/min)	300	150~2800	慢速启动的速度设定
Fn-07	慢速启动针数(针)	2	0~99	慢速启动的针数设定
Fn-08	定长缝自动运行速度(r/min)	3200	300~4500	触发自动功能键后的速度设定
Fn-09	定长缝后自动执行终止回缝功能	1	0~1	1: 执行完一段定长缝后,将自动运行终止回缝; 0: 执行完一段定长缝后,若该段为连续回缝功能,必须重新再行有完全启动动作才可回缝; 2: 连续回缝功能
Fn-10	点动回缝时功能模式选择	1	0~1	1: 点动方式(即在缝纫和停止时均执行回缝动作) 0: 回缝方式(即在缝纫时执行回缝动作,在停止时执行回缝动作)
Fn-11	起始回缝运行模式	1	0~2	0: 受脚踏控制,可在任意上与启动1: 脚踏脚,自动执行回缝动作 2: 脚踏脚控制回缝模式
Fn-12	起始回缝结束模式	1	0~1	1: 起始回缝完成后,自动结束下一段功能; 0: 起始回缝针数完成或自动停止
Fn-13	起始回缝补偿-1	60	1~150	连续回缝段针数补偿
Fn-14	起始回缝补偿-2	60	1~150	起始回缝段针数补偿
Fn-15	终止回缝运行模式	1	0~2	0: 受脚踏控制,可在任意上与启动1: 脚踏脚,自动执行回缝动作 2: 脚踏脚控制回缝模式
Fn-16	终止回缝补偿-1	60	1~150	连续回缝段针数补偿
Fn-17	终止回缝补偿-2	60	1~150	起始回缝段针数补偿
Fn-18	连续回缝运行模式	1	0~2	0: 受脚踏控制,可在任意上与启动1: 脚踏脚,自动执行回缝动作 2: 脚踏脚控制回缝模式
Fn-19	连续回缝补偿-1	60	1~150	连续回缝段针数补偿
Fn-20	连续回缝补偿-2	60	1~150	连续回缝段针数补偿
Fn-21	停针位置选择	1	0~1	0: 无脚踏键时功能设定; 1(上停针) 0(下停针)
Fn-22	慢速启动功能设定	0	0~1	0: 无脚踏键时功能设定; 1(开启) 0(关闭)
Fn-23	剪线自动抬压脚踏设定	0	0~1	0: 无脚踏键时功能设定; 1(开启) 0(关闭)
Fn-24	中途停车自动抬压脚踏设定	0	0~1	0: 无脚踏键时功能设定; 1(开启) 0(关闭)
Fn-25	慢速启动功能设定	0	0~1	0: 无脚踏键时功能设定; 1(开启) 0(关闭)
Fn-26	自动抬压/夹线功能设定	3	0~3	0(关闭) 1(启动) 2(启动) 3(启动) 4(启动) 5(启动) 6(启动) 7(启动) 8(启动) 9(启动) 10(启动) 11(启动) 12(启动) 13(启动) 14(启动) 15(启动) 16(启动) 17(启动) 18(启动) 19(启动) 20(启动) 21(启动) 22(启动) 23(启动) 24(启动) 25(启动) 26(启动) 27(启动) 28(启动) 29(启动) 30(启动) 31(启动) 32(启动) 33(启动) 34(启动) 35(启动) 36(启动) 37(启动) 38(启动) 39(启动) 40(启动) 41(启动) 42(启动) 43(启动) 44(启动) 45(启动) 46(启动) 47(启动) 48(启动) 49(启动) 50(启动) 51(启动) 52(启动) 53(启动) 54(启动) 55(启动) 56(启动) 57(启动) 58(启动) 59(启动) 60(启动) 61(启动) 62(启动) 63(启动) 64(启动) 65(启动) 66(启动) 67(启动) 68(启动) 69(启动) 70(启动) 71(启动) 72(启动) 73(启动) 74(启动) 75(启动) 76(启动) 77(启动) 78(启动) 79(启动) 80(启动) 81(启动) 82(启动) 83(启动) 84(启动) 85(启动) 86(启动) 87(启动) 88(启动) 89(启动) 90(启动) 91(启动) 92(启动) 93(启动) 94(启动) 95(启动) 96(启动) 97(启动) 98(启动) 99(启动) 100(启动) 101(启动) 102(启动) 103(启动) 104(启动) 105(启动) 106(启动) 107(启动) 108(启动) 109(启动) 110(启动) 111(启动) 112(启动) 113(启动) 114(启动) 115(启动) 116(启动) 117(启动) 118(启动) 119(启动) 120(启动) 121(启动) 122(启动) 123(启动) 124(启动) 125(启动) 126(启动) 127(启动) 128(启动) 129(启动) 130(启动) 131(启动) 132(启动) 133(启动) 134(启动) 135(启动) 136(启动) 137(启动) 138(启动) 139(启动) 140(启动) 141(启动) 142(启动) 143(启动) 144(启动) 145(启动) 146(启动) 147(启动) 148(启动) 149(启动) 150(启动) 151(启动) 152(启动) 153(启动) 154(启动) 155(启动) 156(启动) 157(启动) 158(启动) 159(启动) 160(启动) 161(启动) 162(启动) 163(启动) 164(启动) 165(启动) 166(启动) 167(启动) 168(启动) 169(启动) 170(启动) 171(启动) 172(启动) 173(启动) 174(启动) 175(启动) 176(启动) 177(启动) 178(启动) 179(启动) 180(启动) 181(启动) 182(启动) 183(启动) 184(启动) 185(启动) 186(启动) 187(启动) 188(启动) 189(启动) 190(启动) 191(启动) 192(启动) 193(启动) 194(启动) 195(启动) 196(启动) 197(启动) 198(启动) 199(启动) 200(启动) 201(启动) 202(启动) 203(启动) 204(启动) 205(启动) 206(启动) 207(启动) 208(启动) 209(启动) 210(启动) 211(启动) 212(启动) 213(启动) 214(启动) 215(启动) 216(启动) 217(启动) 218(启动) 219(启动) 220(启动) 221(启动) 222(启动) 223(启动) 224(启动) 225(启动) 226(启动) 227(启动) 228(启动) 229(启动) 230(启动) 231(启动) 232(启动) 233(启动) 234(启动) 235(启动) 236(启动) 237(启动) 238(启动) 239(启动) 240(启动) 241(启动) 242(启动) 243(启动) 244(启动) 245(启动) 246(启动) 247(启动) 248(启动) 249(启动) 250(启动) 251(启动) 252(启动) 253(启动) 254(启动) 255(启动) 256(启动) 257(启动) 258(启动) 259(启动) 260(启动) 261(启动) 262(启动) 263(启动) 264(启动) 265(启动) 266(启动) 267(启动) 268(启动) 269(启动) 270(启动) 271(启动) 272(启动) 273(启动) 274(启动) 275(启动) 276(启动) 277(启动) 278(启动) 279(启动) 280(启动) 281(启动) 282(启动) 283(启动) 284(启动) 285(启动) 286(启动) 287(启动) 288(启动) 289(启动) 290(启动) 291(启动) 292(启动) 293(启动) 294(启动) 295(启动) 296(启动) 297(启动) 298(启动) 299(启动) 300(启动) 301(启动) 302(启动) 303(启动) 304(启动) 305(启动) 306(启动) 307(启动) 308(启动) 309(启动) 310(启动) 311(启动) 312(启动) 313(启动) 314(启动) 315(启动) 316(启动) 317(启动) 318(启动) 319(启动) 320(启动) 321(启动) 322(启动) 323(启动) 324(启动) 325(启动) 326(启动) 327(启动) 328(启动) 329(启动) 330(启动) 331(启动) 332(启动) 333(启动) 334(启动) 335(启动) 336(启动) 337(启动) 338(启动) 339(启动) 340(启动) 341(启动) 342(启动) 343(启动) 344(启动) 345(启动) 346(启动) 347(启动) 348(启动) 349(启动) 350(启动) 351(启动) 352(启动) 353(启动) 354(启动) 355(启动) 356(启动) 357(启动) 358(启动) 359(启动) 360(启动) 361(启动) 362(启动) 363(启动) 364(启动) 365(启动) 366(启动) 367(启动) 368(启动) 369(启动) 370(启动) 371(启动) 372(启动) 373(启动) 374(启动) 375(启动) 376(启动) 377(启动) 378(启动) 379(启动) 380(启动) 381(启动) 382(启动) 383(启动) 384(启动) 385(启动) 386(启动) 387(启动) 388(启动) 389(启动) 390(启动) 391(启动) 392(启动) 393(启动) 394(启动) 395(启动) 396(启动) 397(启动) 398(启动) 399(启动) 400(启动) 401(启动) 402(启动) 403(启动) 404(启动) 405(启动) 406(启动) 407(启动) 408(启动) 409(启动) 410(启动) 411(启动) 412(启动) 413(启动) 414(启动) 415(启动) 416(启动) 417(启动) 418(启动) 419(启动) 420(启动) 421(启动) 422(启动) 423(启动) 424(启动) 425(启动) 426(启动) 427(启动) 428(启动) 429(启动) 430(启动) 431(启动) 432(启动) 433(启动) 434(启动) 435(启动) 436(启动) 437(启动) 438(启动) 439(启动) 440(启动) 441(启动) 442(启动) 443(启动) 444(启动) 445(启动) 446(启动) 447(启动) 448(启动) 449(启动) 450(启动) 451(启动) 452(启动) 453(启动) 454(启动) 455(启动) 456(启动) 457(启动) 458(启动) 459(启动) 460(启动) 461(启动) 462(启动) 463(启动) 464(启动) 465(启动) 466(启动) 467(启动) 468(启动) 469(启动) 470(启动) 471(启动) 472(启动) 473(启动) 474(启动) 475(启动) 476(启动) 477(启动) 478(启动) 479(启动) 480(启动) 481(启动) 482(启动) 483(启动) 484(启动) 485(启动) 486(启动) 487(启动) 488(启动) 489(启动) 490(启动) 491(启动) 492(启动) 493(启动) 494(启动) 495(启动) 496(启动) 497(启动) 498(启动) 499(启动) 500(启动) 501(启动) 502(启动) 503(启动) 504(启动) 505(启动) 506(启动) 507(启动) 508(启动) 509(启动) 510(启动) 511(启动) 512(启动) 513(启动) 514(启动) 515(启动) 516(启动) 517(启动) 518(启动) 519(启动) 520(启动) 521(启动) 522(启动) 523(启动) 524(启动) 525(启动) 526(启动) 527(启动) 528(启动) 529(启动) 530(启动) 531(启动) 532(启动) 533(启动) 534(启动) 535(启动) 536(启动) 537(启动) 538(启动) 539(启动) 540(启动) 541(启动) 542(启动) 543(启动) 544(启动) 545(启动) 546(启动) 547(启动) 548(启动) 549(启动) 550(启动) 551(启动) 552(启动) 553(启动) 554(启动) 555(启动) 556(启动) 557(启动) 558(启动) 559(启动) 560(启动) 561(启动) 562(启动) 563(启动) 564(启动) 565(启动) 566(启动) 567(启动) 568(启动) 569(启动) 570(启动) 571(启动) 572(启动) 573(启动) 574(启动) 575(启动) 576(启动) 577(启动) 578(启动) 579(启动) 580(启动) 581(启动) 582(启动) 583(启动) 584(启动) 585(启动) 586(启动) 587(启动) 588(启动) 589(启动) 590(启动) 591(启动) 592(启动) 593(启动) 594(启动) 595(启动) 596(启动) 597(启动) 598(启动) 599(启动) 600(启动) 601(启动) 602(启动) 603(启动) 604(启动) 605(启动) 606(启动) 607(启动) 608(启动) 609(启动) 610(启动) 611(启动) 612(启动) 613(启动) 614(启动) 615(启动) 616(启动) 617(启动) 618(启动) 619(启动) 620(启动) 621(启动) 622(启动) 623(启动) 624(启动) 625(启动) 626(启动) 627(启动) 628(启动) 629(启动) 630(启动) 631(启动) 632(启动) 633(启动) 634(启动) 635(启动) 636(启动) 637(启动) 638(启动) 639(启动) 640(启动) 641(启动) 642(启动) 643(启动) 644(启动) 645(启动) 646(启动) 647(启动) 648(启动) 649(启动) 650(启动) 651(启动) 652(启动) 653(启动) 654(启动) 655(启动) 656(启动) 657(启动) 658(启动) 659(启动) 660(启动) 661(启动) 662(启动) 663(启动) 664(启动) 665(启动) 666(启动) 667(启动) 668(启动) 669(启动) 670(启动) 671(启动) 672(启动) 673(启动) 674(启动) 675(启动) 676(启动) 677(启动) 678(启动) 679(启动) 680(启动) 681(启动) 682(启动) 683(启动) 684(启动) 685(启动) 686(启动) 687(启动) 688(启动) 689

# Industrial Sewing Machine AC Servo Control System Operation Instruction

## 1. Important Safety Instructions

- Using Servo Control system and its accessories safely and properly, be sure to read and get the safety instructions before you use the machine.
- Keep the manual for reference whenever necessary.

Keep strictly to the following instruction which should be noted and prohibited when using the machines. Also noted, there will be some serious accidents which is unlisted in the manual if violate the instructions.

- Observe the following safety instruction before use the machine and avoid all the caution and prohibited items.

### 1.1 Operation Environment

- Only connect the machine to the power supply which conformed to the specification listed in the label.
- Keep away from the electromagnetic interference source to avoid malfunction.
- Do not operate the machine under the site whose temperature is below 5°C or above 45°C.
- Do not operate the machine under the site whose relative humidity is below 30% or above 80%.
- Keep the machine out of the dust.
- Keep away from heat and place the machine in the well ventilated environment.

### 1.2 Installation The Machine

- Keep strictly to the manual to assemble all the part of the machine.
- The power supply must be turned off when changing the needle, tilting the head of the machine and connecting/disconnecting the power plug.
- It's necessary to ground the machine permanently and reliably with appropriate diameter wire and plug to the factory system ground.

### 1.3 Operation

- Set the machine on low speed at the first turning on to check whether the rotation direction is correct.
- Do not press the pedal at the moment the machine is connected to the power supply.
- Do check the setting parameter and switch status before normal work.
- Do not touch the moving parts of the machine, such as hand wheel and needle, while the machine is in operation.
- On alarm, it is necessary to troubleshoot and confirm the safety, reset the alarm parameter before re-running the machine.
- Do not turn on/off the machine power frequently.

### 1.4 Maintenance

- As there are high voltage in the control cabinet, avoid to open the cabinet within 5 minutes after turning off.
- Only the trained expert is allowed to maintain and repair the machine.
- All the components for maintenance and replacement must be provided or qualified by our company.

### 1.5 Technology Specification

Rated Input Voltage	220V±10%
Rated Input Frequency	50/60HZ
Rated Output Power	550W/750W
Maximum Motor Rotation Speed	5000rpm/3500rpm

## 2. Upper Needle Stop Position Setting And Adjustment

The needle stop position must be setted before the first operation, or the machine can't operate normally, and there will be needle broken and locked mechanical issues.

1. Press the key "S" on the same time turn on the power key to enter function setup mode.

2. While entering into function setup mode, the operation panel LCD displays function code setting interface, then press key +/- to set the code.

3. Manual rotates the hand wheel to adjust the needle to the required position. Or alignment the needle position mark point on the hand wheel (POINT ①) and the mark point on the machine head (POINT ②).

4. Then press the key "S" to save and accurate the function, four short tones are heard and it hints finishing the setting.

5. The needle position set in step 3 is just the upper needle position.

Through the "up" and "down" key to trim the position, the motor will be real time rotation, intuitive display whether the adjustment is place.


If the stop position be setted on the right position, the set function will be done.

## 3. Operation Description

### 3.1 Key Function Definition:

Function	Key	Description	Icon
Function Parameter/Edit	P	Enter function parameter edit mode after pressing the key for 2-3S in the operation mode; Quit function parameter edit mode after press the key for 2-3S in the edit mode.	
Setting Parameter Check And Save	S	After setting the function code, press this key to check the preset parameter and then can edit the parameter accordingly; When the parameter is fixed, press key to save the setting and quit.	
Speed Increase/Decrease	▲	Increase the sewing speed	
Parameter Increase/Decrease	▼	Slow down the sewing speed.	
Stitch Setting	+	Increase the parameter	
Stitch Tracking	-	Decrease the parameter	
Auto Function	⊙	Automatic function for constant stitch sewing.	
Needle Stop Position Selection	⏏	Select needle up position stop position. The default is up position when the related icon is lighting on the panel LCD.	
Slow Launch Setting	⏏	Set slow launch function. When the related icon is display on the panel, the function is activated.	
Auto Lift Presser Foot After Pause	⏏	Set presser foot auto-lifting after trimming function. When the related icon is display on the panel, the function is activated.	
Auto Lift Presser Foot After Trimming	⏏	Set presser foot auto-lifting after trimming function. When the related icon is display on the panel, the function is activated.	
Consecutive Reverse sewing	↔	Set consecutive reverse sewing function. When the related icon is display on the panel, the function is activated.	
Free Sewing	⏏	Set free sewing function. When the related icon is display on the panel, the function is activated.	
Start Back-Tracking Sewing	↔	Set start back-tracking sewing function. Continuous press the key, the function will in single back-tracking and dual back-tracking between the switch.	
End Back-Tracking Sewing	↔	Set end back-tracking sewing function. Continuous press the key, the function will in single back-tracking and dual back-tracking between the switch.	
Constant Stitch Sewing	⏏	Execute section E constant stitch sewing. Continuous press the key, the function will in four section sewing, and user-defined multi-section between the switch.	
Line Trimming	✂	When this function is selected, and this icon will be displayed on the panel LCD, and so line trimming function is activated.	
Lift And Fill Up Needle	⏏	Actuate lift and fill up needle function.	
Clamp/Thread Function	⏏	Set the clamp thread function.	

## 4. System Wire Diagram



## 5. Operation Mode Selection

### 5.1 Sewing Mode

The machine enters into sewing mode as default setting after powering on. In the sewing mode, the user can select various kinds of sewing function using setting technology parameter. In sewing mode, the users can switch over between various kinds of sewing function according to their need, but can't modify and set all the system technology parameters.

### 5.2 User Parameter Setting Mode

- In user parameter setting mode, users can adjust various kinds of sewing function of the magnet. The steps are as follows:
- Press key P for 2-3S in the sewing mode to enter into user parameter setting mode.
  - The interface after entering into user parameter setting mode is function ID selection, press +/- to select the required number.
  - After fixing the function ID, press key S to check and modify the related parameter, press +/- to set the required parameter.
  - After fixing the parameter, press key S to save the setting and quit the interface.

### 5.3 System Parameter Setting Mode

- In system parameter setting mode, it's available to adjust kinds of the parameter of the electromagnets and system setting. The system parameter ranges from Fn-40 ~Fn-17. Actual parameter can be set according to the following steps. The steps are as follows:
- Long press key P, in the same time turn on the power switch from off to enter into system parameter setting mode.
  - In this mode, both system parameter and user parameter can be modified.
  - The default interface after entering into system parameter setting mode is function ID selection, press +/- to select number.
  - After fixing the function ID, press key S to check and modify the related parameter, press +/- to set the required parameter.
  - After fixing the parameter, press key S to save the setting and quit the interface.
  - Press key P for 2-3S to quit the system parameter setting mode and back to sewing mode.

## User parameter table:

No.	Items	Default	Range	Contents
Fn-01	Maximum sewing speed (r/min)	3600	100~3000	Maximum speed adjustments
Fn-02	Set accelerated curve (%)	120	10~150	Set the acceleration curve (%)
Fn-03	Start Back-Tacking speed (r/min)	1800	150~2800	Set Start Back-Tacking speed
Fn-04	End Back-Tacking speed (r/min)	1800	150~2800	Set End Back-Tacking speed
Fn-05	Bar-Tacking speed (r/min)	1800	150~2800	Set Bar-Tacking speed
Fn-06	Slow start speed (r/min)	300	150~2800	Set slow start speed
Fn-07	Number of Stitches for slow start	2	0~99	Number of stitches setting for slow start
Fn-08	Automatic Constant-Stitch sewing speed (r/min)	3200	300~4500	Speed adjustment for automatic constant-stitch sewing
Fn-09	Automatic end Back-Tacking sewing	1	0~1	1. After last seam of constant stitch sewing, it will automatic execute the End Back-Tacking sewing function. When turned on, the Stitch-Correction is valid. 0. Automatic End Back-Tacking will not execute after last seam, but can be done by a manual.
Fn-10	Back-Tacking mode selection	1	0~1	0. BROTHER mode (Press TB switch will activate reverse solenoid when other machine is stopped or running). 1. JUKI mode (Press TB switch will activate reverse solenoid only when machine is running).
Fn-11	Start Back-Tacking running mode selection	1	0~2	1. Automatically perform actions 0. Could be arbitrarily stop and start. 2. Accurate Mode
Fn-12	Ending mode of star Back-Tacking	1	0~1	1. Start Back-Tacking is completed automatically continued for next action. 0. After the number of stitches is completed, stop automatically.
Fn-13	Start Back-Tacking compensation-1	60	1~150	Compensation for B part of Start Back-Tacking
Fn-14	Start Back-Tacking compensation-2	60	1~150	Compensation for B part of Start Back-Tacking
Fn-15	End Back-Tacking running Mode	1	0~2	1. Automatically perform actions 0. Could be arbitrarily stop and start. 2. Accurate Mode
Fn-16	End Back-Tacking compensation-1	60	1~150	Compensation for C part of end Back-Tacking
Fn-17	End Back-Tacking compensation-2	60	1~150	Compensation for D part of end Back-Tacking
Fn-18	Bar-Tacking running mode selection	1	0~2	1. Automatically perform actions 0. Could be arbitrarily stop and start. 2. Accurate Mode
Fn-19	Bar-Tacking compensation-1	60	1~150	Compensation for A,C part of Bar-Tacking
Fn-20	Bar-Tacking compensation-2	60	1~150	Compensation for B,D part of Bar-Tacking
Fn-21	Needle stop position selection	1	0~1	Valid only when the operation panel is disconnected, (UP) / 0. (DOWN)
Fn-22	Slow start function selection	0	0~1	Valid only when the operation panel is disconnected, (ON) / 0. (OFF)
Fn-23	Automatic foot lift after trimming function selection	0	0~1	Valid only when the operation panel is disconnected, (ON) / 0. (OFF)
Fn-24	Automatic foot lift when pause	0	0~1	Valid only when the operation panel is disconnected, (ON) / 0. (OFF)
Fn-25	Automatic function selection	0	0~1	Valid only when the operation panel is disconnected, (ON) / 0. (OFF)
Fn-26	Wipe thread function / clamp thread function selection	3	0~3	0(OFF) / 1(Wipe Thread Function ON) / 2(Clamp Thread Function ON) / 3(Kee Thread Control Clamp Thread)
Fn-27	Clamp thread start angle	180	1~300	Clamp thread start angle (Thread length control)
Fn-28	Clamp thread output intensity	30	20~100	Clamp thread output intensity
Fn-30	The remaining thread Length control	180	120~360	The remaining thread Length control
Fn-31	Scissors sensitivity	0	0~50	5 lines Pedal, 6, ALL / 1, HALF / 2, Three combinations Pedal 1. lines Pedal: 3-50 Sensitive

## System parameter table

No.	Items	Default	Range	Contents
Fn-32	Accurate Mode spacing angle	100	0~180	The Bigger of the number the more agile
Fn-35	Foot lifter full time	0	0~1000	The longer the foot lifter drop more slowly
Fn-38	EEPROM selection	2	0~2	0(internal EEPROM) / 1(Stop position and Bar-Tacking in external EEPROM) / 2(Stop position in External EEPROM)
Fn-39	Finished sewing piece counter	—	0~9999	Display the quantity of finished sewing piece
Fn-40	Direction of Motor Rotation	—	0~1	0: When motor stopped, keep lock / 0: No effect
Fn-41	Motor Brake Function	—	0~1	1: enable / 0: disable
Fn-42	Auto running for test function	0	0~1	When the parameter set as 1, the machine will start auto running as sewing function set on the operation panel.
Fn-43	Motor auto-running full time(hr.)	8	1~800	Only valid when Fn-42=1, set the full time for motor auto-running
Fn-44	Motor auto-running on cycle time(s)	3	1~30	Only valid when Fn-42=1, set the motor on time for each running cycle.
Fn-45	Motor auto-running off cycle time(s)	3	1~60	Only valid when Fn-42=1, set the motor off time for each running cycle.
Fn-46	The minimum speed(r/min)	300	100~400	Adjust the minimum speed of the motor
Fn-47	Thread trimming speed(r/min)	300	100~400	Speed is too low may lead to unusual thread, the speed is too high may lead to unstable positioning control
Fn-48	Foot lifter and back-tracking electromagnet operation time to full output (ms)	300	0~990	Foot lifter and back-tracking electromagnet operation time to full output
Fn-49	Back-tracking electromagnet operation duty cycle (%)	30	10~90	Back-tracking electromagnet operate in duty cycle to save the electricity and protect the electromagnet from over-heat.
Fn-50	Motor starting delay time (ms)	50	0~990	Delay the start-time, with automatic present from down
Fn-51	Half step release foot lift	3	0~4	0. (OFF) / 1. (Half step trigger) / 2. (Half step keep) / 3. (Half step follow) / 4. (Disable Half step foot lift)
Fn-52	Safety switch signal selection	0	0~1	1: Keep ON / 0: Keep OFF
Fn-53	Trimming operation delay before the mechanical angle (Degrees)	189	120~250	The degrees between UP position and thread trimming action
Fn-54	Completion of the mechanical angle of the thread trimming action required (Degrees)	360	250~360	Completion of the mechanical angle of the thread trimming action required
Fn-55	Thread take action before the delay time (ms)	10	0~980	The time between UP position and Thread take
Fn-56	Thread take action time (ms)	70	0~9990	Completion of the thread take-up action required time
Fn-57	The time before foot lifter action (ms)	50	0~990	The time between thread take action and Foot lifter action
Fn-58	The time of foot lifter action maintain (s)	3	1~120	The time of foot lifter action maintain
Fn-59	UP needle position adjustment (Degrees)	15	1~30	UP needle position adjustment (15 is the central location)
Fn-60	Down needle position adjustment (Degrees)	180	140~220	Down needle position adjustment
Fn-61	Power on and positioning	1	0~1	1:ON / 0:OFF
Fn-62	The rate of normal stop (%)	925	1~1999	Set the rate of normal stop
Fn-63	The rate of thread trimming stop (%)	925	1~1999	Set the rate of thread trimming stop
Fn-64	Hold time of Back-Tacking (s)	30	1~120	Forced shut-down after hold time.
Fn-65	Low-speed maximum output torque (%)	30	10~80	Low-speed maximum output torque
Fn-66	Low-speed start-up time Selection (UP position enable)	0	0~5	The higher the gear, the start to accelerate the faster 0:OFF
Fn-67	Foot lifter electromagnet operation duty cycle (%)	30	10~90	Foot lifter electromagnet operate in duty cycle to save the electricity and protect the electromagnet from over-heat.

## 6. Auxiliary Function

Fn-68	Sewing machine maintenance	0	0~9999	Set the sewing machine maintenance cycle time. Input (1)1, turn off the maintenance prompt function.
Fn-69	Direct drive UP position deviation angle (degrees X10)	—	0~3600	Direct drive UP position deviation angle (Relative to Z) signal
Fn-70	System fault information code	—	—	—
Fn-71	Encoder pulse number code	—	0~1599	Display encoder pulse number.
Fn-72	Mechanical angle information	—	0~359	Display mechanical angle.
Fn-73	Output current for electromagnet(A) (A)	—	0.0~9.9	Display output current for electromagnet
Fn-74	The pedals speed level (V)	—	0.0~3.3	Display the pedals speed level
Fn-75	Input monitoring of the servo system (G)	—	—	See note ①
Fn-76	Total running time of the sewing machine during the maintenance cycle. Input (0)1, you can clear the total running time.	—	0~9999	Display the total running time of the sewing machine during the maintenance cycle.
Fn-79	Reset to factory initial parameter	—	—	See Section 6.1

### Note ① Description of the contents of Fn-75 parameter monitoring

Different spots-light represents a different meaning.

The following table shows below:

Spot	Signal
[01]	pedal forward signal input
[02]	pedal backward signal input
[03]	back-tracking control switch input
[04]	The safety control switch input
[05]	(BYTRIP) UP position input
[06]	(BYTRIP) down position input
[07]	(HALL) (D) signal
[08]	(HALL) (V) signal
[09]	(HALL) (W) signal
[10]	Bus voltage is too high signal
[12]	encoder (Z) signal

## 6.1 Factory Parameter Initialization

- Refer to clause 5.3 to enter system parameter setting mode.
- Set function ID to Fn-79, Press key S to view and edit parameter.
- Set different code to execute factory parameter initialization in different way. Details refer to the right table. Press key S to activate the initialization.

## 6.2 The Number Of Processing Statistics

Under sewing mode, press S key. The display will show the processing statistics for the number.

## 6.3 Real-time Motor Speed Monitor

Under user parameter setting mode or system parameter setting mode, press the accelerate adjustment key (▲), the display will show the real-time speed of the motor.

## 6.4 Stitch Tracking Remedial Measure

Issue description	Remedial measure
	Root cause: The stitch number of section A is beyond the set value, or the length of section A last stitch is increased, the length of section B first stitch is decreased, which cause the final stitch of section B can't overlap with the initial stitch of section A. Measure: Turn up the parameter of Fn-13 properly.
	Root cause: The stitch number of section A is less than the set value, or the length of the section A last stitch is decreased, the length of section B first stitch increased, which cause the final stitch of section B is over the initial stitch of section A. Measure: Turn down the parameter of Fn-13 properly.

## 7. Troubleshooting And Maintenance

When there is error in the system, the error information will be shown on the panel in the same time, the indicator led will light red. The user can handle the error by the error code according the manual if the error can't be settled, please contact our technician for support. Error code will be indicated in HEX on the panel. Refer to the following picture for Err-1 display.

Error code	Input problem description	Measure
Err-0	Power signal self test error (power on pedal fault detect)	1. Check the connectivity of pedal signal. 2. Release the pedal to neutral position.
Err-1	Stop position signal error	UP-Stop position signal error.
Err-2	EPEPROM read/write data error	Check up external the card reader
Err-3	EPEPROM built-in parameter error	Power-on restart
Err-4	Over-current, over-voltage, over-heat, low-voltage	1. Turn off the machine for at least 30S, and then restart. 2. There maybe some malfunction for the motor power control module. 3. Check whether there are transient interference.
Err-5	Detect high voltage on the DC busbar	1. Turn off the machine for at least 30S, and then restart. 2. Check the power supply voltage.
Err-6	Detect over current for the power supply for electromagnet	1. Turn off the machine for at least 30S, and then restart. 2. Turn off the machine, and check the connectivity of the electromagnet circuit.
Err-7	Stalling	Turn off the machine and check the mechanical parts
Err-8	Motor decoder output signal error	Check the motor output signal line whether there is broken or poor contact.
Err-9	Synchronizer self test error	1. Turn off the machine, and check the connectivity of synchronizer. 2. Replace synchronizer The operation time reaches the maintenance period.
Err-E	Machine(head) maintenance prompt	Please do maintenance for the head, and then enter Fn-78 to reset the accumulated operation time.
Err-F	Safety switch alarming	1. Check whether the head of the machine is turned over. 2. Check the connectivity of the circuit of safety switch.